



- Wood must be soaked in boiling water for at least 2 hours before you try to bend it.
- Run a saw cut for 35 cm through thickness of ski. Use a piece of veneer or plywood and glue in place. Form bend. This method requires no soaking.

